



SpeedDirect
1901 S FM 129
Santo, TX 7472
www.speeddirect.com
sales@speeddirect.com
(800) 425-2776

Front Sway Bar Instructions
Part # ASB-F-760
For 1963 – 1982 Corvette

Technical Note:

When putting a Corvette on jack stands or on a lift always:

- Pop the hood
- Pop the doors
- Release the T-Top locks (if applicable)

This will help relieve stress on the fiberglass.

1. Take note of how the bushings, washers and sleeve are sequenced and remove the original end links located at the end of the sway bar.
2. Remove the frame mount brackets and bushing. Do one side at a time. Be sure to support the center of the sway bar with your hand or jack.
3. Install the new polyurethane bushings onto the sway bar.
4. Install the frame mount bushing brackets.
5. Raise the bar to the frame and adjust the bushings left or right to line up with the frame rails. Tips of the sway bar should face upward.
6. Install the flat washer between the frame and the frame mount bracket on all 4 bolts. This should allow the sway bar to move freely when you rotate it. Torque the 5/16" bolts to 30 ft/lbs.
7. Install the end link bushing kit (Orientation Shown Below). You may need to lift the front wheel in order to start the nut on the threads. Be careful that you do not come off of the jack stands/lift. Pulling down on the bar will also help as well.
8. Tighten the nut up so you see about a 1/4" - 1/2" of thread.
9. Safely remove the jack stands and you're done.

